

BCA 015 AIRBOX

BCA 016 HOSE CLAMP



BCA 004 BRACKET-throttle cable

BCA 001 GASKET

BCA 001 GASKET



BCA 002 INTAKE VALVE



BCA 003 ADAPTOR-carburettor

BCA 005 WASHER



BCA 006 SPRING RING

BCA 007 SCREW



BCA 008 SCREW

BCA 009 GASKET




BCA 009 GASKET



BCA 010 ISOLATING PLATE



BCA 011 CARBURETTOR-assy



BCA 012 ADAPTOR-airbox



BCA 005 WASHER



BCA 006 SPRING RING



BCA 013 SCREW



BCA 014 TUBE-set

